



HETI Uuni & Grilli

Power cleaner for grills and ovens

750 ml, 5 L



Product description

Ready-to-use HETI Uuni & Grill is suitable for cleaning stainless surfaces such as ovens and grills. The product effectively removes grease and stuck-on dirt. HETI Uuni & Grill can be used at temperatures below +70°C. The product is not suitable for aluminium and rough surfaces. Test the resistance of the material on a small area before use. Foam the product onto the surface to be cleaned and allow to act for 1 - 2 min. If necessary, scrub stains with a brush or non-scratch steel scrubber. Rinse with water. Use personal protective equipment. pH 14,0

Composition

<5 % Amphoteric surfactants, anionic surfactants and non-ionic surfactants

Instructions for storing

Store at room temperature. Must not freeze. Shelf life for 2 years in a spray bottle and 5 years in a 5 L container from the date of manufacture if stored correctly.

Total shelf life after opening

1 year

Country of origin

Finland

Manufactured by

Berner Oy



Berner Oy.
Hitsaajankatu 24, 00810 Helsinki
+358 20 690 76 | medlab@berner.fi | bernermedical.fi

Bröderna Berner AB, Berner Medical
Bergkällavägen 27 A, 192 79 Sollentuna
+ 46 8 446 15 06 | info.medical.se@bernercompany.com | bernermedical.se

Recycling instructions

The product must not be discharged undiluted into water or soil. If necessary, small quantities may be disposed of diluted via the sewerage system. Large quantities should be disposed of in accordance with the instructions of the local waste management authority. Packaging plastic is suitable for recycling. The canister, bottle and label are PE plastic suitable for reuse. PE plastic can also be used for material recycling and energy production. 750 ml bottle is made of recycled plastic.

Packaging information

	Product number	Sales unit Qty	Pallet Qty	Sales unit EAN	Pallet EAN
750 ml	1000000853	8 kpl	312 kpl	6414505190977	6414505190984
5 L	33825	3 kpl	108 kpl	6414504237819	6414504313193



750 ml



5 L



Berner Oy.
Hitsajankatu 24, 00810 Helsinki
+358 20 690 76 | medlab@berner.fi | bernermedical.fi

Bröderna Berner AB, Berner Medical
Bergkällavägen 27 A, 192 79 Sollentuna
+ 46 8 446 15 06 | info.medical.se@bernercompany.com | bernermedical.se